

# **PARTS CATALOG**

**Crawler Excavator  
R22-7**

*Use the bookmarks for navigation inside the Parts book*


Tech. Library <https://engine.od.ua>

# **HYUNDAI**

## Excavator R22-7


Page	Contents	Serial_No	Revision_No
<b>1</b>	<b>WORK EQUIPMENT</b>		
1002	WORK EQUIPMENT 1		
1006	WORK EQUIPMENT 2		
<b>2</b>	<b>UPPER FRAME</b>		
2010	SWING FRAME		2009. 5.31 REV.9E
2014	FLOOR PLATE		
2018	CONTROL SYSTEM 1		
2020	CONTROL SYSTEM 2		
2024	CONTROL SYSTEM 3		
2028	CONTROL SYSTEM 4		
2030	CONTROL SYSTEM 5		
2032	TANK UNIT		
2036	ENGINE COVER		
2040	CANOPY		
2042	CABIN		
2046	DOOR(FRONT, SIDE)		
2050	HEATER PIPING		
<b>3</b>	<b>LOWER MACHINE</b>		
3054	TRACK FRAME 1		
3058	TRACK FRAME 2		
<b>4</b>	<b>POWER UNIT</b>		
4062	POWER UNIT 1		2006. 7.31 REV.6G
4066	POWER UNIT 2		
4070	POWER UNIT 3		
<b>5</b>	<b>HYDRAULIC PIPING</b>		
5074	WORK EQUIPMENT PIPING		
5078	PTO PIPING		
5080	UPPER FRAME PIPING 1		
5082	UPPER FRAME PIPING 2		
5084	UPPER FRAME PIPING 3		
5086	UPPER FRAME PIPING 4		
5090	UPPER FRAME PIPING 5		
5092	CHASSIS FRAME PIPING		
<b>6</b>	<b>HYDRAULIC COMPONENT</b>		
6096	CONTROL VALVE 1		2009. 5.31 REV.9E
6098	CONTROL VALVE 2		
6100	BOOM CYLINDER		
6104	ARM CYLINDER		
6108	BUCKET CYLINDER		
6110	SWING CYLINDER		
6112	DOZER CYLINDER		
6114	SWIVEL JOINT		
6116	PUMP		2009. 5.31 REV.9E
6118	DRIVE MOTOR		
6120	TURNING MOTOR		
6122	JOYSTICK VALVE		
6124	SOLENOID VALVE		2009. 5.31 REV.9E
<b>7</b>	<b>ELECTRIC SYSTEM</b>		
7128	ELECTRIC SYSTEM		2006. 6.30 REV.6F
<b>8</b>	<b>LABEL</b>		
8134	LABEL(ENGLISH)		2009. 3.31 REV.9C
8148	TOOLS		
<b>9</b>	<b>OPTION</b>		
9138	LONG ARM		
9140	J/D LEVER PATTERN PIPING		
9144	RADIO		
<b>A</b>	<b>ENGINE BASE</b>		
A010	CRANK CASE		
A020	OIL PAN & GEAR CASE		

A030	CYLINDER HEAD		
A040	MAIN MOVING PARTS		
A050	TIMING PARTS		
A060	FUEL SUPPLY PARTS		
A070	FUEL INJECTION PUMP		
A080	NOZZLE & NOZZLE HOLDER		
A090	FUEL FILTER(A)		
A100	FUEL FILTER(B)		
A110	GOVERNOR PARTS		
A120	LUBRICATING PARTS		
A130	COOLING PARTS		
A150	INTAKE & EXHAUST PARTS		
A170	MUFFLER		
A180	ELECTRIC PARTS		2006. 7.31 REV.6G
A190	STARTER		
A200	ALTERNATOR		
A210	INSTRUMENT PARTS		
A220	REPAIR GASKET KIT		




Item	Part_No	IS	Ord	T	Description	Qty	Serial_No	ITC	Remark
1	XJDH-03976				SWING POST	1			
2	XJDH-03977				PIN-SWING POST	1			
3	XJDH-01148				COLLAR-POST PIN	1			
4	XJDH-01149				WASHER	1			
5	XJDH-00083				BOLT	1			
6	XJDH-01476				PIN	2			
7	XJDH-01181				COLLAR	2			
8	XJDH-00070				BOLT	2			
9	XJDH-00280				WASHER	2			
10	XJDH-03978				BOOM	1			INC 11,12
11	XJDH-01420				.BUSHING	2			
12	XJDH-00362				.SEAL-DUST	2			
13	XJDH-00373				NIPPLE-GREASE	1			
14	XJDH-03979				PIN-BOOM	1			
15	XJDH-01181				COLLAR	1			
16	XJDH-00070				BOLT	1			
17	XJDH-00280				WASHER	1			
18	XJDH-03980				PIN	1			
19	XJDH-01181				COLLAR	1			
20	XJDH-00070				BOLT	1			
21	XJDH-00280				WASHER	1			
22	XJDH-01482				PIN	2			
23	XJDH-01181				COLLAR	2			
24	XJDH-00070				BOLT	2			
25	XJDH-00280				WASHER	2			
26	XJDH-03987				COVER-BOOM CYL	1			

Item	Part_No	IS	Ord	T	Description	Qty	Serial_No	ITC	Remark
27	XJDH-00069				BOLT	1			
28	XJDH-00280				WASHER	1			
29	XJDH-01524				TUBE-VINYL	2			




Item	Part_No	IS	Ord	T	Description	Qty	Serial_No	ITC	Remark
1	XJDH-04104				LEVER-DOZER	1			INC 2
2	XJDH-00320				.BUSHING	2			
3	XJDH-02890				NUT	1			
4	XJDH-01005				GRIP	1			
5	XJDH-04105				SHAFT	1			
6	XJDH-00057				BOLT	2			
7	XJDH-00278				WASHER	2			
8	XJDH-00057				BOLT	1			
9	XJDH-00264				WASHER	1			
10	XJDH-00022				BOLT	1			
11	XJDH-00027				BOLT	1			
12	XJDH-00184				NUT	2			
13	XJDH-04091				END-ROD	2			
14	XJDH-04106				WIRE-PUSH PULL	1			
15	XJDH-00182				NUT	2			
16	XJDH-01402				PIN	2			
17	XJDH-00253				WASHER	2			
18	XJDH-04092				PIN-SPLIT	2			






FOR DRIVE(R)(L)/SWING  
P.T.O./DOZER



FOR ARM



81 FOR BOOM/BUCKET/TURNING


Item	Part_No	IS	Ord	T	Description	Qty	Serial_No	ITC	Remark
1	XJDH-03564				O-RING	2			
2	XJDH-03565				RING-WIPER	2			
3	XJDH-03566				SEAT-SPRING	2			
4	XJDH-03567				SPRING	1			
5	XJDH-03568				SPRING	1			
6	XJDH-03569				SCREW-CAP	1			
7	XJDH-03570				CAP	1			
8	XJDH-02876				BOLT-SOCKET HEAD	2			
9	XJDH-03255				SEAT-SPRING	2			
10	XJDH-03571				SPRING	1			
11	XJDH-03572				POPPET	1			
12	XJDH-03269				SPRING	1			
13	XJDH-03573				SPACER	1			
14	XJDH-03574				END-SPOOL	1			
15	XJDH-03575				CAP	1			
16	XJDH-03252				BOLT-SOCKET HEAD	4			
17	XJDH-03576				O-RING	1			
18	XJDH-03577				RING-WIPER	1			
19	XJDH-03256				O-RING	2			
20	XJDH-03255				SEAT-SPRING	2			
21	XJDH-03571				SPRING	1			
22	XJDH-03578				END-SPOOL	1			
23	XJDH-03256				O-RING	2			
24	XJDH-03575				CAP	1			
25	XJDH-03252				BOLT-SOCKET HEAD	4			

Item	Part_No	IS	Ord	T	Description	Qty	Serial_No	ITC	Remark
1	XJDH-03662				DRIVE MOTOR	2			INC 2-14
2	XJDH-03663				.PACKING ASSY	1			INC 3-6
3	XJDH-03664				..O-RING	1			
4	XJDH-03313				..O-RING	2			
5	XJDH-03315				..O-RING	1			
6	XJDH-03308				..O-RING	1			
7	XJDH-03665				.PACKING ASSY	1			INC 8-14
8	XJDH-03666				..O-RING	1			
9	XJDH-03667				..O-RING	1			
10	XJDH-03317				..SEAL-OIL	1			
11	XJDH-03315				..O-RING	1			
12	XJDH-03313				..O-RING	2			
13	XJDH-03370				..O-RING	2			
14	XJDH-03315				..O-RING	2			

Item	Part_No	IS	Ord	T	Description	Qty	Serial_No	ITC	Remark
1	XJDH-03629				ARM-LONG	1			
2	XJDH-01041				BUSHING	6			
3	XJDH-00362				SEAL-DUST	6			
4	XJDH-03989				COLLAR	1			
5	XJDH-00373				NIPPLE-GREASE	1			
6	XJDH-03630				HOSE	2			

Item	Part_No	IS	Ord	T	Description	Qty	Serial_No	ITC	Remark
1	XJAF-02216				PUMP ASSY-FUEL INJECT	1			
101	XJAF-01191				.HOUSING SUB ASSY	1			
102	XJAF-01194				.HOLDER-DELIVERY	3			
103	XJAF-01816				.O-RING	3			
104	XJAF-01195				.SPRING-DELIVERY	3			
105	XJAF-01197				.GASKET-DELIVERY	3			
106	XJAF-01198				.VALVE SUB ASSY	3			
107	XJAF-01200				.ELEMENT SUB ASSY	3			
108	XJAF-01202				.SLEEVE SUB ASSY	3			
109	XJAF-01205				.SEAT-SPRING UPPER	3			
110	XJAF-01189				.SPRING-PLUNGER	3			
111	XJAF-01207				.SEAT-SPRING LOWER	3			
N112	@				.PLATE-TAPPET SHIM	AR			NOT
113	XJAF-01209				.TAPPET SUB ASSY	3			
114	XJAF-01217				.SCREW-AIR BLEEDER	1			
115	XJAF-01220				.WASHER-DRAIN SCREW	1			
116	XJAF-01219				.SCREW-HOLLOW	1			
117	XJAF-01226				.NIPPLE-SWIVEL	1			
118	XJAF-01221				.WASHER-DRAIN UNION	2			
119	XJAF-01216				.PLATE-LOCK	3			
120	XJAF-01824				.SCREW-W/WASHER	3			
121	XJAF-01215				.RACK ASSY-CONTROL	1			
122	XJAF-01823				.SCREW-COUNTERSUNK	2			
123	XJAF-01224				.BRACKET-STOP WIRE	1			
124	XJAF-01213				.PIN-TAPPET GUIDE	3			
N	@				NOT INDIVIDUALLY SUPPLIED	AR			NOT

# MUFFLER



Item	Part_No	IS	Ord	T	Description	Qty	Serial_No	ITC	Remark
2	XJAF-01591				MUFFLER ASSY	1			
3	XJAF-01590				BRACKET	1			
4	XJAF-01869				BOLT-W/WASHER	4			
5	XJAF-01866				BOLT-W/WASHER	3			
6	XJAF-01551				GASKET	2			
7	XJAF-02037				ELBOW	1			
8	XJAF-01987				STUD	2			
9	XJAF-01985				STUD	2			
10	XJAF-01986				STUD	4			
11	XJAF-02201				NUT	8			
12	XJAF-02002				WASHER-SPRING	8			
13	XJAF-01998				WASHER-PLAIN	4			